

Model L-929 Decay Drum Series



Ludlum Measurements, Inc.

Introduction

The DOT 17H RAD WASTE (new) drums are 4-pi lined with 3 mm (1/8 in.) or 6.4 mm (1/4 in.) of lead. These decay drums come in three sizes, 15, 30, or 55 gallons. The removable overlapping lid has two options, the standard lid or the optional hinged lid. The provided standard lid is a sealed snap-on lid that is better for a one time use that will then be hauled off. The optional hinged lid has an 8 x 8 in. access hole and handle on top for easier access that would be better for day to day disposal.

The standard lid is provided with the drum if the optional hinged lid is not purchased. Four-wheel dollies are also optional.



Lead-Lined Steel Drums
(Shown, 15 gal drum with optional dolly and hinged lid)

Model	Dimensions	Lead	Weight	Standard Lid PN	Hinged Lid PN
L-929-15-1/4	ID 32.7 cm dia. x 57.2 cm tall (OD) (ID 12.875 in. dia. x 22.50 in. tall (OD))	6.4 mm (1/4 in.)	68 kg (150 lbs)	99-9963	99-9962
L-929-15-1/8		3 mm (1/8 in.)	39 kg (85 lbs)	99-9961	99-9960
L-929-30-1/4	ID 44.5 cm dia. x 67.1 cm tall (OD) (ID 17.50 in. dia. x 26.437 in. tall (OD))	6.4 mm (1/4 in.)	145 kg (320 lbs)	99-9967	99-9966
L-929-30-1/8		3 mm (1/8 in.)	73 kg (160 lbs)	99-9965	99-9964
L-929-55-1/4	ID 31.4 cm dia. x 82.9 cm tall (OD) (ID 12.375 in. dia. x 32.625 in. tall (OD))	6.4 mm (1/4 in.)	166 kg (365 lbs)	99-9970	99-9969
L-929-55-1/8		3 mm (1/8 in.)	91 kg (200 lbs)	99-9584	99-9968

Optional Dollies

15 gal PN: 99-9971
30 gal PN: 99-9972
55 gal PN: 99-9973